

SINGLE MODULATING VALVE

464 Series


Service Instructions



TABLE 1 (Specifications)

Model Number	Repair Kit Number	Brake Pressure Setting	
		bar	(PSI)
06-464-122	06-400-183	86.2 ± 3.5	(1250 ± 50)
06-464-124	06-400-183	60.3 ± 3.5	(875 ± 50)
06-464-126	06-400-183	86.2 ± 3.5	(1250 ± 50)
06-464-128	06-400-183	60.3 ± 3.5	(875 ± 50)

NOTE: If your product number is not listed, please call MICO, Inc. for information.



MICO is a registered trademark of MICO, Inc. MICO is registered in the U.S. Patent and Trademark Office as well as in Australia, Canada, Indonesia, Japan, Peoples Republic of China, South Korea, and the European Community.



Innovative Braking and Controls Worldwide

MICO, Incorporated

1911 Lee Boulevard / North Mankato, MN U.S.A. 56003-2507

Tel: +1 507 625 6426 Fax: +1 507 625 3212

DISASSEMBLY

(Refer to Figure 1)

1. Separate pedal (29) from base (24) by removing one e-ring (25) from pin (22) and removing pin.
2. Remove bushings (23) from base (24).
3. Inspect pin (26) and cam (27) to be sure cam is in good working order and moving freely. It is unnecessary to remove pin (26), cam (27) or e-ring (28) unless damaged.
4. Separate valve assembly from base (24) by removing cap screws (30) and washers (31).
5. Remove boot (21) from piston (20).
6. Remove piston (20), springs (18, 17 & 15), retainer (16) and shim(s) (14) from housing bore. Note number of shim(s) removed from housing.
7. Bearing (19) need not be removed from housing bore. **NOTE: Excessive wear on both bearing (19) and piston (20) may require replacement.**
8. Remove retainer assembly (13) from housing bore. **NOTE: Ball is pressed into retainer.**
9. Loosen nut (1) and remove end plug (4) from housing. Remove spring (5), nut (1), washer (2), and o-ring (3) from end plug (4).

NOTE

Spool (9) and sleeve (7) are manufactured as a matched set. Do not intermix spool (9) or sleeve (7) with other parts.

10. Using a wooden dowel remove spacer (11), sleeve (7) and spool (9) assembly from housing bore. **NOTE: Be careful not to scratch or mar sleeve (7) or housing bore.**
11. Separate spacer (11) and spool (9) from sleeve (7). **NOTE: Excessive wear on either spool (9) or sleeve (7) may require replacement.**
12. Remove o-ring (8) from spacer (11). Remove cup (10) from spacer (11) or spool (9) depending on model. Note direction of cup (10).
13. Remove o-ring (8) and o-rings (6) from sleeve (7). **NOTE: Be careful not to damage cup or o-ring grooves or bore.**

ASSEMBLY

(Refer to Figure 1)

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT, SPOOL (9) AND SLEEVE (7) WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

1. Clean all parts thoroughly before assembling.
2. Install new cup (10) in spacer (11) or on spool (9) depending on model. Note direction of cup. Install one new o-ring (8) on spacer (11).
3. Install new o-rings (6) on large diameter end of sleeve (7) and one new o-ring (8) on smaller diameter end of sleeve (7).
4. Carefully insert spool (9) into sleeve (7). Note direction of spool.
5. Insert spacer (11) into housing bore through end plug (4) end of housing. Note direction of spacer.
6. Carefully insert sleeve (7) and spool (9) assembly into housing bore using a wooden dowel. Note direction of assembly.
7. Install spring (5) into housing bore.
8. Install end plug (4) and torque 10.9-20.3 N·m (96-180 lb·in) to seat sleeve. Then loosen end plug 1/4 turn and torque 1.1-6.0 N·m (10-60 lb·in). Install new o-ring (3), washer (2) and nut (1). Hold end plug (4) with a wrench and torque nut 67.8-81.4 N·m (50-60 lb·ft).
9. Install retainer assembly (13) in housing. **NOTE: Depress retainer assembly (13) until it bottoms on spacer (11). Spool (9) and retainer (13) must return when released. If the spool and retainer do not return when released, the bore of sleeve (7) may be damaged.**
10. Install shim(s) (14), springs (15, 17 & 18), retainer (16) and piston (20) in housing bore. **NOTE: Be sure to install the same number of shim(s) as were removed during disassembly.**
11. Install new boot (21) on housing (12).
12. Attach valve assembly to base (24) using new cap screws (30) and washers (31). Torque cap screws 24.4-29.8 N·m (18-22 lb·ft).
13. Install new bushings (23) in base (24).
14. Lubricate pin (22) with a good quality polymer base moly grease. Align pedal (29) between ears of base (24) and insert pin (22). Install e-ring (25).

NOTE

If cap screw (32) or nut (33) are loosened or removed, they must be properly reset. With all parts assembled, adjust screw (32) to allow valve spool to fully release. After adjustment is made tighten nut (33).

After service, the valve must develop the pressure indicated in the specifications, TABLE 1. Shim(s) (14) may be added or removed to obtain the correct pressure setting.

● Items included in Repair Kit




FIGURE 1

BLEEDING

Brake lines should be bled very carefully as soon as the valve is installed in the machine. Air in the system will not allow the brakes to release properly and may severely damage them.

1. Start engine and allow accumulator to reach full charge. Shut down engine, then slowly apply and release brakes, waiting one minute between applications until brakes will not apply. Repeat this step three times.
2. Operate engine to maintain accumulator pressure within working limits

throughout the bleeding procedure.

3. Open bleeder screw at wheel closest to brake valve and apply brakes cautiously until all air is bled out of line. Then close bleeder screw. Repeat this step at each wheel, moving to the next closest wheel from the brake valve each time, as follows:
 - a. Left front
 - b. Right front
 - c. Right rear
 - d. Left rear

4. Release brake pressure for at least one (1) minute.
5. Apply brakes, holding pedal down 10 seconds; then release pressure for one (1) minute. Repeat this step two more times.
6. Repeat step 3.
7. Check for system leaks and be sure of proper brake operation.

SERVICE CHECKS FOR 464 SERIES SINGLE PEDAL VALVES

BRAKES SLOW TO APPLY

1. No or improper gas charge in accumulator
 1. **Check gas charge**
 2. Brakes not properly adjusted
 2. **Adjust brakes**
 3. Inoperative brakes
 3. **Check brakes**
 4. Hydraulic lines or fittings leaking
 4. **Check for leaks and repair**
 5. Inoperative automatic adjuster (Goodrich Hi-torque Brakes only)
 5. **Check adjuster operation**
 6. Damaged hydraulic brake lines
 6. **Check lines for dents that restrict flow of oil**

BRAKES WILL NOT RELEASE

1. Pedal angle out of adjustment
 1. **Check for proper pedal angle**
 2. Inoperative brakes
 2. **Check brakes**
 3. Inoperative automatic adjusters
 3. **Check operation of adjusters**
 4. Inoperative brake valve
 4. **Replace brake valve**

INSUFFICIENT BRAKES

1. No oil or low oil level in tank
 1. **Check oil level in tank**
 2. Brakes not properly adjusted
 2. **Check brake adjustment**
 3. Oil or grease on brake lining
 3. **Clean or install new linings**

4. Brake line damaged
4. **Check lines and replace**
5. Inoperative automatic adjusters
5. **Check operation of adjusters**
6. No or improper gas charge in accumulator
6. Check gas charge
7. Inoperative brakes
7. **Check brakes**
8. Brake valve inoperative
8. **Replace valve**

EXCESSIVE BRAKING

1. Inoperative brakes
 1. **Check brakes**
 2. Inoperative brake valve
 2. **Replace brake valve**

BRAKES WILL NOT RELEASE COMPLETELY

1. Brakes not properly adjusted
 1. **Adjust brakes**
 2. Inoperative brakes
 2. **Check brakes**
 3. Pedal angle out of adjustment
 3. **Adjust pedal angle**
 4. Inoperative wheel cylinders
 4. **Replace wheel cylinders**
 5. Inoperative automatic adjuster
 5. **Check operation of adjusters**
 6. Air in brakes (when automatic adjusters used Goodrich Hi-torque Brakes only)
 6. **Bleed brakes**

7. Inoperative brake valve
7. **Replace brake valve**
8. Back pressure on return line too high
8. **Remove restriction**

NO BRAKES

1. No oil in hydraulic system
 1. **Check oil level in tank**
 2. Broken or damaged brake line
 2. **Check lines for breaks or damaged condition**
 3. Brakes not properly adjusted
 3. **Adjust brakes**
 4. Inoperative system relief valve
 4. **Check pressure in pressure line to valve**
 5. Worn pump
 5. **Check pressure in pressure line to valve**
 6. Inoperative automatic adjuster
 6. **Check brake line pressure**
 7. Inoperative or worn brakes
 7. **Check brakes**
 8. Inoperative brake valve
 8. **Replace brake valve**

PEDAL KICKBACK WHEN BRAKES ARE APPLIED

1. Air in brakes
 1. **Bleed brakes**

SERVICE DIAGNOSIS

(Refer to Figures 1 & 2)

BRAKES WILL NOT RELEASE COMPLETELY

1. Piston (20) sticking
2. Pedal angle out of adjustment
3. Spring (5) broken

BRAKE WILL NOT RELEASE

1. Binding spool (9)
2. Damaged sleeve (7)
3. Piston (20) binding

NO BRAKES

1. Piston (20) binding
2. Broken spring (15)

EXCESSIVE BRAKING

1. Too many shims (14) installed in valve

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE APPLIED

1. Damaged spool (9)
2. Damaged sleeve (7)
3. O-rings (6) leaking
4. O-rings (8) leaking

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE NOT BEING USED

1. Damaged spool (9)
2. Damaged sleeve (7)
3. O-rings (6) leaking
4. Spring (5) broken

INSUFFICIENT BRAKES

1. Broken pressure regulating spring (15)
2. Boot cut, allowing dirt to accumulate under piston (20) flange

MICO could not possibly know of and give advice with respect to all conceivable applications in which this product may be used and the possible hazards and/or results of each application. MICO has not undertaken any such wide evaluation. Therefore, anyone who uses an application which is not recommended by the manufacturer, first must completely satisfy himself that a danger will not be created by the application selected, or by the particular models of our product that is selected for the application.

MICO has made every attempt to present accurate information in catalogs, brochures and other printed material. MICO can accept no responsibility for errors from unintentional oversights that may exist. Due to a continuous program of product improvement, materials, specifications, and product documentation are subject to change without notice or obligation.