

TANDEM MODULATING VALVE with Pilot Apply





Service Instructions

TABLE 1 (Specifications)

Complete Unit Model Number	Valve Assembly Number	Repair Kit Number	Brake Pressure Setting		Complete Unit Model Number	Valve Assembly Number	Repair Kit Number	Brake Pressure Setting	
			bar	(PSI)				bar	(PSI)
06-466-342 (HO)	20-100-661	06-400-178	55.2 ± 3.5	(800 ± 50)	06-466-970 (HO)	20-100-649	06-466-178	40.0 ± 3.5	(580 ± 50)
06-466-389 (HO)	20-200-202	06-400-178	77.6 ± 5.2	(1125 ± 75)	06-466-982 (HO)	20-100-661	06-400-178	55.2 ± 3.5	(800 ± 50)
06-466-549 (HO)	20-200-247	06-400-178	30.0 ± 1.7	(435 ± 25)	06-466-992 (HO)	n/a	06-400-178	60.0 ± 3.5	(870 ± 50)
06-466-947 (HO)	20-100-904	06-400-178	44.8 ± 3.5	(650 ± 50)	20-100-720 (HO)	n/a	06-400-238	103.4 ± 5.2	(1500 ± 75)
06-466-954 (HO)	20-100-601	06-400-178	77.6 ± 5.2	(1125 ± 75)	20-100-802 (HO)	n/a	06-400-178	77.6 ± 5.2	(1125 ± 75)
06-466-960 (HO)	20-100-601	06-400-178	77.6 ± 5.2	(1125 ± 75)	20-100-886 (HO)	n/a	06-400-238	144.8 ± 3.5	(2100 ± 50)

HO = Mineral Base Hydraulic Oil

NOTE: If your product number is not listed, contact ZF Off-Highway Solutions Minnesota Inc. for information.



⚠ WARNING

Installation and test note: Piston (21) must be retained mechanically. This will prevent it from blowing out at high velocity if an incorrect connection occurs from power source to tank ports. **Be sure the tank ports are connected directly to tank.** Failure to do this could result in serious injury or death.

This publication is not subject to any update service. Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. ZF Off-Highway Solutions Minnesota Inc. reserves the right to revise the information presented or to discontinue the production of parts described at any time.



ZF Off-Highway Solutions Minnesota Inc.

1911 Lee Boulevard / North Mankato, MN U.S.A. 56003

Tel: +1 507 625 6426 Fax: +1 507 625 3212

MODELS:

- 06-466-389 06-466-954
- 06-466-960 20-100-720
- 06-466-970 20-100-802
- 06-466-992 20-100-886

DISASSEMBLY

(Refer to Figures 1, 3, and Table 2)

NOTE

Housings (7 & 13) and spools (8, 11 & 12) are manufactured as matched sets. These sets, housing and spool(s), should not be intermixed with other parts.

1. Remove boot (22) from piston (21) and housing (13).
2. Remove piston (21), springs (18, 19 & 20), shim(s) (17) and retainer assembly (16) from housing (13). **NOTE: Be aware of the number of shim(s) being removed from housing. Not all models use spring (20).**
3. Carefully remove cup (15) and seal (14) from housing (13) bore. **NOTE: Be careful not to scratch or mar housing bore.**
4. Remove end plug (1), retainer (2), and spring (4) from housing (7). Remove o-ring (3) from end plug (1). **OTE: Retainer (2) is not used in all models.**
5. Separate housings (7 & 13) by removing cap screws (5) and washers (6). Remove o-rings (9 & 10) from housings (7 & 13).
6. Carefully remove spools (8, 11, & 12) from housings (7 & 13). **NOTE: Be careful not to damage spools or housing bores.**

CAUTION

Do not intermix spools and housings. Spool (8) and housing (7) are a matched set as are spools (11 & 12) and housing (13).

7. Remove bleeder screw (23). Remove o-ring (24) from bleeder screw (23).

ASSEMBLY

(Refer to Figures 1, 3, and Table 2)

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

1. Clean all parts thoroughly before assembling.
2. Install new o-rings (9 & 10) in proper o-ring pockets on housings (7 & 13).
3. Lubricate spools (11 & 12) with clean system fluid and carefully slide into bottom end of housing (13) bore. Note direction and order of spools (11 & 12). **NOTE: Spools must slide freely into bore. If any parts are damaged, a new valve assembly may be required.**
4. Reassemble housings (7 & 13) using cap screws (5) and washers (6). Use Loctite 242 on cap screws and torque 27.1-33.9 N·m (22-25 lb·ft). **NOTE: Make sure housings line up correctly and that o-rings (9 & 10) remain in the pockets during assembly.**
5. Lubricate spool (8) with clean system fluid and carefully slide into housing (7) bore. Note direction of spool (8). **NOTE: Spool must slide freely into bore. If either part is damaged, a new valve assembly may be required.**
6. Install new o-ring (3) on end plug (1).
7. Install spring (4), retainer (2) and end plug (1) into housing (7). Torque end plug 47.5-54.2 N·m (35-40 lb·ft). **NOTE: Retainer (2) is not used in all models.**
8. Carefully install new cup (15) and new seal (14) into housing (13) bore. Note direction and order of cup and seal. **NOTE: Be careful not to scratch or mar housing bore.**




TABLE 2 O-ring Identification

Item Number	Description	Quantity
3	O-ring, 0.644 I.D. x 0.830 O.D. x 0.093 thick	1
9	O-ring, 0.364 I.D. x 0.504 O.D. x 0.070 thick	1
10	O-ring, 0.980 I.D. x 1.120 O.D. x 0.070 thick	1
24	O-ring, 0.351 I.D. x 0.495 O.D. x 0.072 thick	1

9. Assemble springs (18, 19, & 20), shim(s) (17) and retainer assembly (16) in piston (21). **NOTE: Not all models use spring (20).**
10. Carefully install piston (21) assembly into housing (13) bore.
11. Install new boot (22) on housing (13) and piston (21).
12. Install new o-ring (24) on bleeder screw (23). Install bleeder screw (23) in housing (13) and torque 13.6-20.3 N·m (10-15 lb·ft).

NOTE

After service, the valve must develop the pressure indicated in the specifications, TABLE 1. Shim(s) (17) are used to obtain the correct pressure setting. Contact ZF Off-Highway Solutions Minnesota Inc. if brake pressure setting is not able to be obtained.

MODELS:
06-466-342
06-466-549
06-466-947
06-466-982

DISASSEMBLY

(Refer to Figures 2, 4, and Table 3)

NOTE

Housings (7 & 13) and spools (8, 11 & 12) are manufactured as matched sets. These sets, housing and spool(s), should not be intermixed with other parts.

1. Remove boot (22) from piston (21) and housing (12).
2. Remove piston (21), springs (19 & 20), retainer (18), spring (17), shim(s)(16) and retainer assembly (15) from housing (12). **NOTE: Be aware of the number of shim(s) being removed from housing.**
3. Carefully remove cup (14) and seal (13) from housing (12) bore. **NOTE: Be careful not to scratch or mar housing bore.**
4. Remove end plug (1), and spring (3) from housing (6). Remove o-ring (2) from end plug (1).
5. Separate housings (6 & 12) by removing cap screws (4) and washers (5). Remove o-rings (8 & 9) from housings (6 & 12).
6. Carefully remove spools (7, 10, & 11) from housings (6 & 12). **NOTE: Be careful not to damage spools or housing bores.**

CAUTION

Do not intermix spools and housings. Spool (8) and housing (7) are a matched set as are spools (11 & 12) and housing (13).

7. Remove bleeder screw (23). Remove o-ring (24) from bleeder screw (23).

ASSEMBLY

(Refer to Figures 2, 4, and Table 3)

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

1. Clean all parts thoroughly before assembling.
2. Install new o-rings (8 & 9) in proper o-ring pockets on housings (6 & 12).
3. Lubricate spools (10 & 11) with clean system fluid and carefully slide into bottom end of housing (12) bore. Note direction and order of spools (10 & 11). **NOTE: Spools must slide freely into bore. If any parts are damaged, a new valve assembly may be Required.**
4. Reassemble housings (6 & 12) using cap screws (4) and washers (5). Use Loctite 242 on cap screws and torque 27.1-33.9 N·m (22-25 lb·ft). **NOTE: Make sure housings line up correctly and that o-rings (8 & 9) remain in the pockets during assembly.**
5. Lubricate spool (7) with clean system fluid and carefully slide into housing (6) bore. Note direction of spool (7). **NOTE: Spool must slide freely into bore. If either part is damaged, a new valve assembly may be required.**
6. Install new o-ring (2) on end plug (1).
7. Install spring (3) and end plug (1) into housing (6). Torque end plug 47.5-54.2 N·m (35-40 lb·ft).
8. Carefully install new cup (14) and new seal (13) into housing (12) bore. Note direction and order of cup and seal. **NOTE: Be careful not to scratch or mar housing bore.**




FIGURE 4

TABLE 3 O-ring Identification

Item Number	Description	Quantity
2	O-ring, 0.644 I.D. x 0.830 O.D. x 0.093 thick	1
8	O-ring, 0.364 I.D. x 0.504 O.D. x 0.070 thick	1
9	O-ring, 0.980 I.D. x 1.120 O.D. x 0.070 thick	1
24	O-ring, 0.351 I.D. x 0.495 O.D. x 0.072 thick	1

9. Assemble springs (19 & 20), retainer (18), spring (17), shim(s) (16) and retainer assembly (15) in piston (21).
10. Carefully install piston (21) assembly into housing (12) bore.
11. Install new boot (22) on housing (12) and piston (21).
12. Install new o-ring (24) on bleeder screw (23). Install bleeder screw (23) in housing (12) and torque 13.6-20.3 N·m (10-15 lb·ft).

NOTE

After service, the valve must develop the pressure indicated in the specifications, TABLE 1. Shim(s) (16) are used to obtain the correct pressure setting. Contact ZF Off-Highway Solutions Minnesota Inc. if brake pressure setting is not able to be obtained.

BLEEDING

Brakelines should be bled very carefully as soon as the valve is installed in the machine. Air in the system will not allow the brakes to release properly and may severely damage them.

1. Start engine and allow accumulator to reach full charge. Shut down engine, then slowly apply and release brakes, waiting one minute between applications until brakes will not apply. Repeat this step three times.
2. Operate engine to maintain accumulator pressure within working limits throughout the bleeding procedure.

3. Open bleeder screw at wheel closest to brake valve and apply brakes cautiously until all air is bled out of line. Then close bleeder screw. Repeat this step at each wheel, moving to the next farthest wheel from the brake valve each time, as follows:
 - a. Left front
 - b. Right front
 - c. Right rear
 - d. Left rear
4. Release brake pressure for at least one (1) minute.

5. Apply brakes, holding pedal down 10 seconds; then release pressure for one (1) minute. Repeat this step two more times.
6. Repeat step 3.
7. Check for system leaks and be sure of proper brake operation.

SERVICE CHECKS FOR MODULATING BRAKE VALVES

BRAKES SLOW TO APPLY

1. No or improper gas charge in accumulator
 1. **Check gas charge**
2. Brakes not properly adjusted
 2. **Adjust brakes**
3. Inoperative brakes
 3. **Check brakes**
4. Hydraulic lines or fittings leaking
 4. **Check for leaks and repair**
5. Inoperative automatic adjuster (Goodrich Hi-torque Brakes only)
 5. **Check adjuster operation**
6. Damaged hydraulic brake lines
 6. **Check lines for dents that restrict flow of oil**

INSUFFICIENT BRAKES

1. No oil or low oil level in tank
 1. **Check oil level in tank**
2. Brakes not properly adjusted
 2. **Check brake adjustment**
3. Oil or grease on brake lining
 3. **Clean or install new linings**
4. Brake line damaged
 4. **Check lines and replace**
5. Inoperative automatic adjusters
 5. **Check operation of adjusters**
6. No or improper gas charge in accumulator
 6. **Check gas charge**
7. Inoperative brakes
 7. **Check brakes**
8. Brake valve inoperative
 8. **Replace valve**

SERVICE DIAGNOSIS

(Refer to Figures 1 and 3)

BRAKES WILL NOT RELEASE COMPLETELY

1. Piston (21) binding
2. Pedal angle out of adjustment
3. Spring (4) broken

BRAKES WILL NOT RELEASE

1. Binding spool (8, 11, or 12)
2. Piston (21) binding

SERVICE DIAGNOSIS

(Refer to Figures 2 and 4)

BRAKES WILL NOT RELEASE COMPLETELY

1. Piston (21) binding
2. Pedal angle out of adjustment
3. Spring (3) broken

BRAKES WILL NOT RELEASE

1. Binding spool (7, 10, or 11)
2. Piston (21) binding

EXCESSIVE BRAKING

1. Inoperative brakes
 1. **Check brakes**
2. Inoperative brake valve
 2. **Replace brake valve**

BRAKES WILL NOT RELEASE COMPLETELY

1. Brakes not properly adjusted
 1. **Adjust brakes**
2. Inoperative brakes
 2. **Check brakes**
3. Pedal angle out of adjustment
 3. **Adjust pedal angle**
4. Inoperative wheel cylinders
 4. **Replace wheel cylinders**
5. Inoperative automatic adjuster
 5. **Check operation of adjusters**
6. Air in brakes (when automatic adjusters used Goodrich Hi-torque Brakes only)
 6. **Bleed brakes**
7. Inoperative brake valve
 7. **Replace brake valve**
8. Back pressure on return line too high
 8. **Remove restriction**

NO BRAKES

1. No oil in hydraulic system
 1. **Check oil level in tank**
2. Broken or damaged brake line
 2. **Check lines for breaks or damaged condition**
3. Brakes not properly adjusted
 3. **Adjust brakes**

NO BRAKES

1. Piston (21) binding
2. Broken spring (19)

OUTLET PRESSURE TOO HIGH (EXCESSIVE BRAKING)

1. Too many shims (17) installed in valve

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE APPLIED

1. Damaged spool (8, 11, or 12)
2. Damaged housing (7 & 8)

NO BRAKES

1. Piston (21) binding
2. Broken spring (17)

OUTLET PRESSURE TOO HIGH (EXCESSIVE BRAKING)

1. Too many shims (16) installed in valve

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE APPLIED

1. Damaged spool (7, 10, or 11)
2. Damaged housing (6 & 12)

4. Inoperative system relief valve

4. Check pressure in pressure line to valve

5. Worn pump
5. **Check pressure in pressure line to valve**
6. Inoperative automatic adjuster
6. **Check brake line pressure**
7. Inoperative or worn brakes
 7. **Check brakes**
8. Inoperative brake valve
 8. **Replace brake valve**

PEDAL KICKBACK WHEN BRAKES ARE APPLIED

1. Air in brakes
 1. **Bleed brakes**

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE NOT BEING USED

1. Damaged spool (8, 11, or 12)
2. Spring (bottom) (7 & 13) broken

INSUFFICIENT BRAKES

1. Broken pressure regulating spring (19)
2. Pedal travel is inhibited

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE NOT BEING USED

1. Damaged spool (4)
2. Spring (bottom) (3) broken

INSUFFICIENT BRAKES

1. Broken pressure regulating spring (10)
2. Pedal travel is inhibited