

# Wheel Mount MULTIPLE DISC BRAKE



## Service Instructions

**NOTE:**

This service sheet covers model numbers:

- 13-587-044
- 13-587-070
- 13-587-088

**REPAIR KITS**

(Refer to page 3 for item numbers)

Number	Description	Includes
12-501-403	Repair Kit for 13-587-044 earlier design (uses one rotor disc)	Case Seal (6) Back-up Rings (8 & 11) O-rings (7 & 10) Stator Disc (12) Rotor Disc (13) Return Plate (14) Springs (15) Bearings (3 & 19) Oil Seal (20)
12-501-404	Repair Kit for 13-587-044 later design (uses two rotor discs)	Case seal (6) Back-up Rings (8 & 11) O-rings (7 & 10) Stator Discs (12) Rotor Discs (13) Return Plate (14) Springs (15) Bearings (3 & 19) Oil Seal (20)
12-501-428	Repair Kit for 13-587-070 13-587-088	Case Seal (6) Back-up Rings (8 & 11) O-rings (7 & 10) Stator Disc (12) Rotor Disc (13) Return Plate (14) Springs (15) Bearings (3 & 19) Oil Seal (20)

This publication is not subject to any update service. Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. ZF Off-Highway Solutions Minnesota Inc. reserves the right to revise the information presented or to discontinue the production of parts described at any time.



**ZF Off-Highway Solutions Minnesota Inc.**

1911 Lee Boulevard / North Mankato, MN U.S.A. 56003

**Tel:** +1 507 625 6426 **Fax:** +1 507 625 3212

## NOTE

This literature services various models in this brake series. The components shown in Figures 1, 2, and 3 may appear different than what is found in your brake.

## DISASSEMBLY

(Refer to Figures 1, 2, and 3)

1. Remove straight key (22) and retaining ring (1) from shaft (21).
2. Support brake housing and carefully remove shaft (21) by pressing out of bearing (3) and bearing (19).
3. Position brake assembly so pressure plate (5) is facing up. A suitable holding fixture is useful to keep brake in position. Remove two cap screws (4) and pressure plate (5).

## ⚠ CAUTION

Pressure plate (5) is under spring tension of approximately 907 kgf (2000 lb). The two cap screws (4) should be loosened evenly to relieve this force. If a hydraulic press is available, 1361 kgf (3000 lb) maximum, the pressure plate can be held in position while removing the cap screws.

4. Remove piston (9) from pressure plate (5).
5. Remove o-rings (7 & 10) and back-up rings (8 & 11) from piston (9). **NOTE: Be careful not to scratch or mar piston.**
6. Remove case seal (6) from cover plate (18).
7. Remove stack assembly, consisting of stator discs (12), rotor discs (13), return plate (14) from cover plate (18).
8. Before removing springs (15) record the spring pattern for reassembly purposes. Remove dowel pins (17), springs (15), and spring retainer (16) from cover plate (18).
9. Remove oil seal (20) and bearing (19) from cover plate (18).
10. Remove retaining ring (2) from pressure plate (5) and press bearing (3) out of pressure plate.

## ASSEMBLY

(Refer to Figures 1, 2, and 3)

SEE FRONT COVER FOR ITEMS INCLUDED IN KITS. LUBRICATE ALL RUBBER COMPONENTS FROM KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

1. Clean all parts thoroughly before assembling.
2. Press new bearing (19) into cover plate (18) until flush with inside of cover plate (18).
3. Install new oil seal (20) in cover plate (18). Note direction of oil seal (20).
4. Install shaft (21) through bearing (19) in cover plate (18).
5. Install dowel pins (17), spring retainer (16), and new springs (15) in cover plate (18). Be sure to install new springs (15) according to the spring pattern recorded during disassembly. Contact MICO if you have questions regarding spring pattern.
6. Install new return plate (14), new rotor discs (13), and new stator discs (12) over dowel pins (17) and spline of shaft (21). **NOTE: See Figure 1a for 13-587-044 earlier design stacking arrangement.**
7. Install new o-rings (7 & 10) and new back-up rings (8 & 11) on piston (9). Note order of o-rings and back-up rings. **NOTE: Be careful not to scratch or mar piston.**
8. Carefully insert piston (9) into pressure plate (5). Note direction of piston (9). Be careful not to shear o-rings or back-up rings.
9. Install new case seal on cover plate (18).
10. Position pressure plate (5) on cover plate (18) aligning dowel pins (17) with holes in pressure plate. Install cap screws (4) and tighten evenly to draw pressure plate (5) to cover plate (18). Torque cap screws 115.3-122.0 N·m (85-90 lb·ft).

## NOTE

If available, a hydraulic press can be used to clamp pressure plate (5) to cover plate (18) while installing and tightening cap screws (4). Be sure to support shaft (21) during this process.

11. Support the brake assembly and shaft (21) so the bearing shoulder on shaft (21) is above the bearing shoulder in pressure plate (5). Press new bearing (3) onto shaft (21) and into pressure plate (5) until it bottoms on the shoulder of shaft (21). Install retaining ring (1).
12. Press on the outer race of new bearing (3) until it bottoms on the shoulder in pressure plate (5) bore. Shaft (21) must rotate freely. Install retaining ring (2) in pressure plate (5).
13. Install straight key (22).

## ⚠ CAUTION

If hydraulic bench testing is performed on the brake assembly, release pressure should not exceed 69.0 bar (1000 PSI) unless four additional bolts, SAE grade 5 or better, are used for supplemental clamping.

See page 1 for items included in kits.






Figure 1a

FIGURE 1



**FIGURE 2**  
13-587-044 earlier design  
(uses one rotor disc)



**FIGURE 3**  
13-587-044 later design  
(uses two rotor discs)

## BLEEDING

1. Install brake in system and connect pressure lines.
2. Bleed pressure release section of brake by pressurizing side inlet port and allowing air to escape from top port. Pressure should not exceed 6.9 bar (100 PSI) during bleeding.
3. Apply sufficient pressure to release brake and check for proper operation in system.

## SERVICE DIAGNOSIS

PROBLEM	CAUSE	EXPLANATION	ACTION
Brake slips	A. Excessive pressure in hydraulic system	If there is back pressure in the actuation line of the brake, holding torque will be reduced.	Check filters, hose size, restrictions in other hydraulic components.
	B. Oil in a brake designed for dry use	Wet linings generate 67% of the dry torque rating.	Check piston seals. <b>NOTE: Internal components will need to be inspected, cleaned, and replace as required</b>
	C. Disc plates worn	The thickness of the disc stack sets the torque level. A thin stack reduces torque.	Check disc thickness and contact ZF Off-Highway Solutions Minnesota Inc.
	D. Springs are broken or have taken permanent set	Broken or set springs can cause reduced torque, a rare occurrence.	Check release pressure and contact ZF Off-Highway Solutions Minnesota Inc. (May need servicing with a new kit).
Brake drags or runs hot	A. Low actuation pressure	The brake should be pressurized to a minimum of 1.38 bar (20 PSI) over the full release pressure under normal operating conditions. Lower pressures will cause the brake to drag thus generating heat.	Attach pressure gauge to bleed port and check pressure with system on.
	B. Bearing failure	If bearing should fail, a large amount of drag can be generated.	Replace the bearing. Refer to kits on page 1.
Brake will not release	A. Stuck or clogged valve	Brakes are designed to come on when system pressure drops below stated release pressure. If pressure cannot get to the brake, the brake will not release.	Attach pressure gauge to bleed port. Check for adequate pressure. Replace defective line or component.
	B. Bad o-rings	If release piston will not hold pressure, the brake will not release.	Replace o-rings. Refer to kits on page 1.
	C. Discs frozen	These brakes are designed for only limited dynamic braking. A severe emergency stop or prolonged reduced release pressure operation may result in this type of damage.	Replace disc stack. Refer to kits on page 1.